



剎車活門系列

BRAKE VALVE
SERIES



h HNTC.
BRAKE VALVE ASSY
刹車總泵ASSY
HINO MH
47160-1860

R/KIT=44069-1560-H



h HNTC.
BRAKE FOOT VALVE
刹車總泵
HINO GF LEG
47160-2041

R/KIT=44069-1560-H



h HNTC.
BRAKE FOOT VALVE
刹車總泵
HINO MA
47160-2191

R/KIT=44069-1560-H



h HNTC.
BRAKE VALVE ASSY
刹車總泵
CW520 CK450
241-02904

R/KIT=9324-2059-H



h HNTC.
BRAKE VALVE ASSY
刹車總泵(雙層).350P
FP517 MP618
241-02903 E-6

R/KIT=9324-2059-H



h HNTC.
PEDAL, AIR BRAKE
刹車踏板總成
FP415 CW520 CW54
MC660804



h HNTC.
PEDAL, AIR BRAKE
刹車踏板總成
SH MBS MCR
47110-1582



h HNTC.
BRAKE VALVE ASSY
刹車總泵ASSY
P11C/330P K13C-TV/360P
47150-1080



h HNTC.
BRAKE FOOT VALVE
刹車總泵
HINO SH MBS MSH MCS
47160-1652



BRAKE FOOT VALVE
 剎車總泵 付螺絲*4
 VO FM12
 20410545
 R/KIT=3093073-H



BRAKE FOOT VALVE
 剎車總泵
 VO FM12
 20374068
 R/KIT=3093073-H



VALVE, BRAKE FOOT
 煞車總泵. HINO 500 SERIES
 FG / FD / FC
 47160-3292-H IN 8 / OUT 12



BRAKE FOOT VALVE
 煞車總泵(入8/出T12)長頸
 FG(15.5T) GH(17T)
 47160-3322-H IN=8 OUT=12



BRAKE FOOT VALVE
 剎車總泵 700 SERIES
 HINO E13C SH1E FG
 47160-3311 IN=8 OUT=10



BRAKE VALVE ASSY
 剎車總邦ASSY
 P114/124 340/360
 1324663



BRAKE VALVE ASSY
 剎車總邦ASSY
 P113 K113 SC310 320
 1314047



VALVE, BRAKE FOOT
 剎車總邦(高113mm)無踏板
 FSR FVR FRR
 1-48100-750-4-H



BRAKE VALVE ASSY
 剎車總泵
 EXR340 EXR330
 241-02900



VALVE, CAB CONTROL
駐車開關
SH MSH SH331
47930-1070



VALVE, CAB CONTROL
駐車開關
LSH
47930-1570



VALVE, CAB CONTROL
駐車開關(壓通)長桿型
EXR320 TMK V10(320) 10PB-98
1-48460-145-0H



VALVE, CAB CONTROL
駐車開關
EXR
1-48460-198-0



VALVE, CAB CONTROL
駐車開關
FP415 FP517
MC804585



VALVE, CAB CONTROL
駐車開關
CK450 CW520
45260-00Z00
R/KIT=45260-99025



BRAKE VALVE ASSY
剎車總泵
FK416 FM515 FK330
241-02124



CUT VALVE KIT
駐車開關活門修理包
E13C SH1E 420P
44039-1050



BRAKE VALVE KIT
剎車總泵修理包
SH1E FS1E GH1J
47069-1030



KIT, AIR BRAKE VALVE
刹車總泵修理包(1324663)
P114 SA340/SA360
4613159072-H



KIT, AIR BRAKE VALVE
刹車總泵修理包(1314047)
P112-113 SC310/320
1374605



KIT, BRAKE VALVE
刹車總邦修理包
FP517 FP519
9324-2059

KIT, BRAKE VALVE
刹車總泵修理包
FP415 CW54 CW520
9324-2046



KIT, LEVELING VALVE
平衡活門修理包
MP518 MS615 9370-0044



KIT, LEVELING VALVE
避震器平衡活門修理包
LCM LRM LFS
44069-4373



LEVELING VALVE
車道避震氣囊平衡閥(側有孔)
K113 (BUS)
475110-H



VALVE, CAB LEVELING
避震器平衡活門
K114 SC340
1430545 (464 007 010 0)



VALVE, CAB LEVELING
車頭水平閥
MAN:19414 FE414
81.43610.6129 (464 007 001 0)



VALVE, CAB LEVELING
避震器平衡活門
LSH FP517
49770-1460
MC056527



VALVE, CAB LEVELING
避震器平衡活門
LSH FP517 FP418
49770-1296



VALVE, CAB LEVELING
巴士平衡活門
LCM LRM
49770-1254
49770-1244



HAND BRAKE VALVE A'SSY
手煞車活門(座椅邊)
FP517/350 FP51J
MK449782-H



HAND BRAKE VALVE A'SSY
手煞車活門(巴士)
MP518 MS715
MC807370-H



VALVE, LEVELING
平衡活門
MP618 MP610 MS513
703-01404 LH 03364-28001
703-01405 RH 03364-29001



VALVE, SUPPLY
空氣避震器供氣活門
MP618 MS715 FP517
MC880117



VALVE, QUICK
快放活門14m/m*3
FP415 CK450
MC803411
EXR330 EXR340
1-48410-052-1 14m/m*3



VALVE, QUICK RELEASE
后刹車室三通活門
LSH(拖車)14x11m/m*2
44550-1030



TRAILER RELAY VALVE
板台刹車總邦總成
RE-6
110200



VALVE, PRESS CONTRON
后刹車室控制活門
SH K13C MSH
44760-1040



VALVE, CUT
同步刹車活門
SH LSH K13C
44080-1010



VALVE, DOUBLE CHECK
雙向活門
SH K13C
44520-1020



VALVE, BRAKE CHECK
單向活門
FP419 FP517 FK330
MC837932



SYNCHRO VALVE
同步刹車活門
FP517
MC886775-H



SYNCHRO VALVE
同步刹車活門
FP415 EXR FV
MC821909-H
1-48460-173-0



EXPANDER, BRAKE 1SET=6Pcs
楔形刹車分泵(前後同) X 6PCS.
E13C-T SH1E
47510-1950-H



BRAKE EXPANDER, WHEEL
楔形刹車分泵前/后相同
FP51J RM11F
MC889050



VALVE, EX BRAKE
排汽刹車缸
EF750 EM100
17470-2222



CYLINDER, EXHAUST BRAKE
排氣剎車缸
MGH2H MFD2H MGD2H
17470-2553



CYLINDER, EXHAUST BRAKE
排氣剎車缸
8DC91 6D22T 6D24T
ME151757-H



CYLINDER, EXHAUST BRAKE
排氣剎車缸
CW520 CK450 CW54
20313-97018-H



VALVE, EX BRAKE
排汽剎車缸
EF750 EM100
17470-2221



VALVE, EX BRAKE
排汽剎車缸
H07CT H06CT
17470-2551



CYLINDER, EX BRAKE
排氣剎車控制缸
EXR
1-22190-533-0



CYLINDER, EX BRAKE
排氣剎車控制缸(轉牙)
6WA-1T 6WG-1 EXR360
8-94395444-0



CYLINDER, EX BRAKE
排汽剎車控制缸
FP415 CW520 EXR
ME053885 ME063716



CYLINDER, EX BRAKE
排汽剎車控制缸
EF750 GD FF
17490-1471 17490-1671



REPAIR KIT, EX VALVE
排汽剎車控制缸修理包
K13C
17303-1020



REPAIR KIT, EX VALVE
排汽剎車控制缸修理包
K13C-TE
17303-1030



REGULATOR, AIR PRESS
氣壓限制器
7.0kg-8.5kg 44530-1110

REGULATOR, AIR PRESS
氣壓限制器
6.5kg-8.5kg 44530-1160



REGULATOR, AIR PRESS
氣壓限制器
6.5kg-7.5kg 44530-1170



REGULATOR, AIR PRESS
氣壓限制器
6.5kg-7.5kg 44530-1311
7.0kg-8.0kg 44530-1370
6.0kg-7.0kg 44530-1301



REGULATOR, AIR PRESS
氣壓限制器
7.0kg-8.5kg 44530-1321
7.5kg-8.5kg 44530-1360
7.5kg-9.0kg 44530-1340
8.0kg-9.0kg 44530-1330



REGULATOR, AIR PRESS
氣壓限制器
7.0kg-8.5kg 47540-90061

REGULATOR, AIR PRESS
氣壓限制器
6.8kg-8.0kg 47540-Z0005



GOVERNOR, AIR
氣壓限制器
7.0kg-8.5kg MC826122

GOVERNOR, AIR
氣壓限制器
7.0kg-8.2kg MC826442



GOVERNOR, AIR
氣壓限制器
7.0kg-8.2kg MC808718



REGULATOR, AIR PRESS
氣壓限制器(7.5kg-8.5kg)
6WA1 340P(拖) 藍
1-48350058-0



REGULATOR, AIR PRESS
氣壓限制器(6.9kg-8.0kg)
6BG1 6HE1T ECM
1-48350059-0



REGULATOR, AIR PRESS
氣壓限制器(7.5kg-8.5kg)
10PDI
1-48350063-0



AIR GOVERNOR
氣壓限制器(7-8.5)
P114 FL12 VOLVO*20"
3944252



GOVERNOR, AIR
氣壓限制器
7.6kg-5.8kg
MC802149
47540-Z0001 47540-Z0001
1-48350037-0 1-48350037-0
408704-2201 408704-2201



SAFETY VALVE
安全活門(鐵)
FV515 FP419 FK337
MC826288



VALVE, SAFETY
安全活門(包橡皮)
HINO ALL
44780-1020-H



SAFETY VALVE
安全活門
FP415 FV SH
MC820238



CHECK VALVE
單向活門(S型)彎
SH FV CW520 EXR ALL
44510-1280/1090
MC821448



HNTC
CHECK VALVE
單向活門(L型)
SH MBS CK450 CW520
44510-1190
47570-Z2008



HNTC
COCK VALVE
放水開關(圓型)
CW520 UD
47502-Z2001



HNTC
DRAIN COCK
放水開關
EXR TD
1-48312-004-1



HNTC
DRAIN COCK
放水開關
HINO ALL
44850-1030



HNTC
DRAIN COCK
放水開關
FV415 FP418
MC817017



HNTC
HIGH / LOW VALVE
十速高低檔控制活門
FUSO M120 M12-3
RIGHT HAND DRIVER
ME659565



HNTC
HIGH / LOW VALVE
十速高低檔控制活門
KATO HOIST CAR
RIGHT HAND DRIVER
ME659568



HNTC
H/L CONTROL VALVE
十速高低檔控制球頭
T/M: M120 M12-3
LEFT HAND DRIVER
ME659566



HNTC
REDUCE VALVE
減壓活門 有網子
HINO
S4458-01071 3.4kg
44580-1071
R/KIT 44069-2230



REDUCE VALVE
 減壓活門 六角螺帽
 HINO

S4456-01120 2.2kg
 S4456-01040 2.4kg
 S4456-01050 3.7kg
 S4456-01061 3.8kg
 S4456-01080 4.0kg
 MC820437
 MC832887
 MC862643



EXHAUST BRAKE CYLINDER
 排氣剎車缸總成
 4D34T 4D31T 4D31
 MB390857



EXHAUST BRAKE CHAMBER
 排氣剎車制動室
 4D34T 4D31T 4D31
 ME729715-H



RELAY VALVE, AIR MASTER
 車道邊調節活門. A/M可用
 FP415 FP418D
 243-04029-H



RELAY VALVE (5 HOLE)
 車道邊調節活門(五孔). 消音
 E13C-T 5孔
 44540-2310



RELAY VALVE (4 HOLE)
 調節活門、上*11/下入22出*22消音
 LSH E13-T 4孔
 44080-E0070-H



AIR MASTER RELAY VALVE
 調節活門總成(八卦小)、3孔
 3孔LSH(三/四期) FG GH
 44540-2271



RELAY VALVE
 調節活門總成
 9730110010



RELAY VALVE 0.28BAR
 調節活門總成. 上1/F3
 DW大宇. 0.28BAR
 P1373300050-H

RELAY VALVE 0.55BAR
 調節活門總成. 上1/F3
 DW大宇. 0.55BAR
 P96802495-H



VALVE, DOUBLE CHECK
 雙向活門(耳.3母)2分PT牙
 EF750 K13C
 44520-1010-H



VALVE, DOUBLE CHECK
 雙向活門(耳)雙邊粗牙*2分
 FV515 FP519
 MC832660-H



VALVE, DOUBLE CHECK
 雙向活門(耳)雙母凸*細牙1.0
 FP415 FP418D
 MC806021-H



VALVE, DOUBLE CHECK
 雙向活門(八卦)上公*下1母1公
 RP517
 MC806028-H



VALVE, DOUBLE CHECK
 雙向活門(八卦)上公*雙邊母
 FV515 FP519
 MC838113-H